



## **Datavideo FS-30**

**ProdCode: DATAFS30**

Foot Switch



[Download Images] (.zip file)

### **Features**

- Foot Switch
- Compatible with the [TP-700](#), [TP-800](#) and [TP-900](#) and tablet based teleprompters
- Supports control of both scrolling text and slides

S-30 foot switch control for direct wired control. The FS-30 foot switch connects via USB and offers three pedals with independent functions. The FS-30 uses non-contact photoelectric sensors for near silent operation.

The FS-30 supports control of both scrolling text and slides.

### **No need to set any control options**

The FS-30 will work with all [TP-700](#), [TP-800](#), [TP-900](#) and tablet based teleprompters running dvPrompter Plus version 1581 or newer.

Connecting the FS-30 to the white USB port on the teleprompters 15" LCD monitor, the FS-30 will work as soon as its connected, there is no need to set any control options within the dvPrompter Plus application.

