



Ikan PT-Pedal

ProdCode: IKAPTPEDAL

Teleprompter Foot Control Pedal



[\[Download Images\]](#) (.zip file)

Features

- Teleprompter Foot Control Pedal
- Control Teleprompter Script by Foot
- Plug-&-Play with Prompter Pro 4
- Three Control Pedals
- For Studio Use, Conferences, and Meetings
- Compatible with Prompter Pro Software
- Includes Pedal Sound Dampeners

Control your Ikan teleprompter and set your own pace with the Foot Control Pedal from Ikan. Designed to work with the Ikan Beam Splitter Glass Teleprompters, this wired foot controller connects to your computer via a USB cable to control different aspects of your prompter sessions such as scroll speed, start, and stop. The Teleprompter Foot Pedal includes dampeners that dramatically reduce the sound of the pedals when they are pressed down. Just plug the USB cable in and you're ready to start controlling your script with Prompter Pro 4.

The foot pedal's curved design facilitates right- or left-foot configurations. It connects to your computer's Ikan's Prompter Pro software and three spaced pedals offer simple prompter controls. Use the center pedal to start or stop your session, use the left pedal to slow down scroll speed, and use the right pedal to increase scroll speed. Use on a flat surface for better control.

Control start, stop, and scroll speed with three pedals Curved design facilitates right- or left-foot configurations Compatible with Ikan's Prompter Pro software for prompter session control Connects to any computer running Microsoft Windows 11, 10, 8, or 7 via a 5? standard USB cable

In the box:

- 1x Teleprompter Foot Pedal

