



## **PGYTECH Roller Camera Backpack**

**ProdCode: PGYPCB180**

Dual Mode Camera Backpack / Trolley Case



[\[Download Images\]](#) (.zip file)

### **Features**

- Dual Mode Camera Backpack / Trolley Case
- Versatile 2-in-1 design: Switch seamlessly between trolley case and backpack
- DIY dividers and 30L large main compartment for secure equipment storage.
- PU double-row wheels: Durable, quick-release for extra space and comfort
- 10L Expandable front compartment for gimbals, clothing, and more.
- Three-stage wide aluminium handle: Balanced, easy pull, and space-efficient.

## **Trolley Case Mode**

With 360 degree spinner wheels, effortless maneuvering for your photography journey.

## **Backpack Mode**

Hidden back panel for a quick switch and easy carry, versatile for any scenario.

## **Customisable Storage**

Professional DIY divier system, great storage plus secure protection.

## **10L Expandable Space**

Quick zip expansion for easy storage of gimbals, clothing and more.

## **Quick Release Double Row Spinner Wheels**

- Stable smooth maneuvering
- Wheels can be quickly removed

## **Balanced Wide Handle**

Great space efficiency, effortless grip and balanced maneuvering.

## **Digital Organiser Bag Included**

Designed for batteries and accessories, this bag can be side-pocketed or used a tote. Quick detach for easy access and hassle free security check.

## **Organised Compartments for Smart Storage**

- Quick access front zipper pocket
- Dedicated laptop/tablet slot for up to 16" devices
- Front zipped top pocket for smaller items

## **Other Features**

- Straps for securing external equipment
-

- The main compartment zipper has a lock slot for use with security locks
- High-performance PU coating, durable, scratch resistant and easy to clean
- YKK zipper, waterproof and durable
- Concealed AirTag pocket
- Multiple handle design for easy carrying
- Rain cover included
- The molded base creates a light body and ensures smoother pull

