

PGYTECH Roller Camera Backpack

ProdCode: PGYPCB180

Dual Mode Camera Backpack / Trolley Case



[Download Images] (.zip file)

Features

- Dual Mode Camera Backpack / Trolley Case
- Versatile 2-in-1 design: Switch seamlessly between trolley case and backpack
- DIY dividers and 30L large main compartment for secure equipment storage.
- PU double-row wheels: Durable, quick-release for extra space and comfort
- 10L Expandable front compartment for gimbals, clothing, and more.
- Three-stage wide aluminium handle: Balanced, easy pull, and space-efficient.

Trolley Case Mode

With 360 degree spinner wheels, effortless maneuvering for your photography journey.

Backpack Mode

Hidden back panel for a quick switch and easy carry, versatile for any scenario.

Customisable Storage

Professional DIY divier system, great storage plus secure protection.

10L Expandable Space

Quick zip expansion for easy storage of gimbals, clothing and more.

Quick Release Double Row Spinner Wheels

- Stable smooth manuevering
- Wheels can be quickly removed

Balanced Wide Handle

Great space efficiency, effortless grip and balanced manuevering.

Digital Organiser Bag Included

Designed for batteries and accessories, this bag can be side-pocketed or used a tote. Quick detach for easy access and hassle free security check.

Organised Compartments for Smart Storage

- Quick access front zipper pocket
- Dedicated laptop/tablet slot for up to 16" devices
- Front zipped top pocket for smaller items

Other Features

Straps for securing external equipment

- The main compartment zipper has a lock slot for use with security locks
- High-performance PU coating, durable, scratch resistant and easy to clean
- YKK zipper, waterproof and durable
- Concealed AirTag pocket
- Multiple handle design for easy carrying
- Rain cover included
- The molded base creates a light body and esnures smoother pull

